



How To Operate Cordless Blinds

Cordless blinds are now the best option for most windows especially when the home has young children and/or pets. Cordless Blinds have been awarded the “Best For Kids” rating from the C.P.S.C. in 2019.

In order to operate the Blinds properly, and keep them in good working order, please follow along with these few simple steps:

1. To Lower the Blind:

Beginning with the Blind in the raised position, make sure the Slats are in the “Open” / “Flat” / “See Thru” / Position. Grasp the Bottomrail firmly using Two Hands spaced evenly and pull down **slowly** until fully expended.

2. To Tilt the Slats:

After the Blind is Fully Lowered, Grasp the Wand and Rotate to Tilt the Slats Open To Closed.

Do Not Over Rotate as that might damage the mechanism.

3. To Raise the Blind:

With the blind in the Fully “Open” position, grasp the Bottomrail firmly using Two Hands spaced Evenly and begin to raise up **slowly**, and “Level” remembering NOT to raise one side more than the other.

4. Uneven or Unlevel Blinds:

If the blind is hanging uneven or is unlevel, it can be corrected by simply first, raising it to the upper most position – Then grasping the bottomrail firmly with two hands spaced evenly and begin to pull down while applying more force on the side that is “higher” allowing the cords to retract and begin to equalize with each other. Pull the blind down to the fully extended length.

This process may need to be done 2-3 times depending on the severity of the issue.